

OE POLARICE + POWERBAR 70

Connection guide

DRD-BUNDLE-POLARICE

1 MAINS SUPPLY



2m starter lead

UK plug to female 3-pole connector
Connects to the under-desk input.

2 UNDER-DESK POWER



POWERBAR 70

4 UK sockets beneath the desk
Output feeds the desktop unit.

3 DESKTOP POWER



PolarICE desktop unit

2 UK sockets + TUF USB charger
Factory-fitted power drop lead.

ONE SUPPLY. SIX UK SOCKETS. DESKTOP USB CHARGING.

Connect the desktop GST power lead to the POWERBAR output. USB specification follows the selected unit.

Connect all components before plugging into the wall. Follow the supplied installation instructions.

All outlets share one supply. Observe all component ratings and allow cable slack. Schematic only; not to scale.