

WIELAND COUPLERS

Connection guide

GST leads | Clip removal and connection

1 REMOVE THE CENTRAL CLIP



START / INTER lead connector

Remove the clip circled in red from the **female START lead** or **male P-PACK DESK connector on the INTER lead**.

2 CONNECT TO EITHER OPTION BELOW



Wieland coupler

1-in / 2-out, 3-out or 5-out.
Insert the prepared connector into the matching coupler socket.

GST power feed unit

Insert the prepared connector into the matching GST socket on the power feed unit.

REMOVE THE CLIP FIRST. THEN CONNECT AND CHECK.

Switch off and disconnect the power supply before handling the connectors.

Check for a fully seated, secure locking fit. If it will not fit or lock, stop and contact DRD.